

CARGADORES VARIOS

F-908

12 V
4 A - 8 A
MANUAL /AUTOMATIC



F-77

12 V
5 A - 10 A
AUTOMATIC



F-2916

12 V - 24 V
6 A - 12 A
MANUAL / AUTOMATIC



CARGADORES MANTENIMIENTO

F-2106

6 V
750 mA
AUTOMATIC



F-2201

12 V
750 mA
AUTOMATIC



CARGADORES HF

F-2504

12 V
4 A
AUTOMATIC



F-2912

12 V
2 A - 6 A - 12 A
AUTOMATIC



F-2507

12 V
7 A
AUTOMATIC



ARRANCADORES

F-2000

12 V 400 A
1000 A PICO



F-2001

12 V 600 A
1500 A PICO

